



INSTALLATION INSTRUCTIONS

RF-RGBW-3AAA



⚠ WARNING

These products may represent a possible shock or fire hazard if improperly installed or attached in any way. Products should be installed in accordance with these instructions, current electrical codes, and/or the current National Electric Code (NEC).

⚠ WARNING

This controller is battery operated and requires 3x AAA batteries (not included).

SAFETY INFORMATION


- Read all instructions before beginning; Save these instructions for future use.
- To reduce the risk of fire, electric shock, or injury to persons, pay close attention to this manual and stay within its guidelines when using this product.
- This controller is rated IP20; avoid the sun and moisture.
- Avoid using controller in areas where extreme hot, cold, dust, or humidity exist.
- This controller is suitable for indoor, dry locations only.
- Always be sure to store this controller in an area with proper ventilation to avoid overheating.

SYNCING CONTROLLER TO RECEIVER (SEE FIGURES 1 & 2):

This controller is battery operated and requires 3x AAA batteries (not included). This controller requires a Radio Frequency receiver for operation (REC-5A-4Z or REC-5A-4Z-WiFi sold separately).

1. Press the power button on the controller once to turn on power to the controller.
2. Press the “Learning Key” on the receiver.
3. Select a zone by pressing one of the four zone buttons on the controller, then touch color temperature wheel to activate controller.
4. Once successfully synced, the connected light source will blink.
5. Repeat steps 2-3 when syncing multiple receivers to a single controller.
6. Press and hold the “Learning Key” to clear out saved sync data when wanting to reset scenes or zones.

FIGURE 1




OPERATING CONTROLLER (SEE FIGURE 2):

This controller is battery operated and requires 3x AAA batteries (not included).

1. Press power button in center of color wheel for On/Off power control. The power indicator light will turn on when remote is awake.
2. Touch and slide the color wheel for independent color control.
3. Press the pre-set R/G/B/W buttons to turn On/Off corresponding pre-set color; press and hold to dim corresponding color.
4. Press the brightness buttons for Up/Down RGB dimming control; White can only dim with corresponding W+ button.
5. Press the speed adjust buttons for Up/Down speed control.
6. To utilize color run auto effect, press the color run auto effect button to toggle through 10 pre-set modes (1-On, 1-Off, 2-On, 2-Off, Etc.); Press and hold for chasing color run mode.
7. To select a zone, press one of the eight zone buttons once. Press and hold a zone button to turn zone On/Off. Memory can select multiple zones simultaneously.

FIGURE 2



CARE AND MAINTENANCE:

1. For cleaning, use a soft, dry or damp cloth. Do not use harsh chemicals or abrasives.
2. This controller is battery operated and requires 3x AAA batteries (not included). If swallowed, batteries could cause severe injury or death. Seek medical attention immediately. Non-rechargeable batteries are not to be recharged. Remove exhausted batteries from the product; Please dispose of batteries properly. Do not dispose of batteries in fire; Batteries may explode or leak.