

INSTALLATION INSTRUCTIONS

REC-5A-4Z



SYNCING RECEIVER WITH A RADIO FREQUENCY CONTROLLER (SEE FIGURE 3):

This receiver requires a Trulux Radio Frequency controller for operation (sold separately). Each receiver can be synced to a maximum of 8 Trulux RF Controllers at one time.

1. Touch the power icon on the controller once to turn on power to the controller.
2. Press the “Learning Key” on the receiver.
3. Select a zone by touching one of the four zone icons on the controller, then touch the slide dimmer to activate controller.
4. Once successfully synced, the connected light source will blink.
5. Repeat steps 2-3 when syncing multiple receivers to a single controller.
6. Press and hold the “Learning Key” for over 3 seconds to clear out saved sync data when wanting to reset scenes or zones.

FIGURE 3

